

SOD LAYER



REQUIREMENTS

FEATURES & BENEFITS



Sod Layer: No special requirement.

- Automatic spindle-arm brakes to prevent unwanted unrolling.
- Self-contained sod cutting blade.
- Built-in storage for sod staples.
- Compact sod after installation using the sod layer with optional sod roller.
- Relief valve prevents "over squeezing" of sod rolls.

Description: Whether laying sod is a normal part of your day-to-day operation or just an occasional chore, the Bobcat® sod layer attachment can make the job go more quickly and efficiently. The sod layer attachment can carry and lay a roll of sod up to 1219 mm wide, making it ideal for larger landscaping jobs. And because it mounts to the front of a Bobcat® loader, it's manoeuvrable enough for those smaller jobs where space restrictions are a concern.

TECHNICAL SPECIFICATIONS

Description	Part Number	Width (cm)	Sod Roll Width (mm)	Arm Cylinders (mm)	Weight (kg)	Control Kit Required	Working Flow	First use installation time
Sod Layer, 185 cm	6906783	185	609 - 1219	50 X 25 X 470	286	No	Standard	None

COMPATIBILITY CHARTS

Description	Part Number	Compact Track Loaders						Skid Steer Loaders and All-Wheel Steer Loaders													
		MT55	T110	T450	T590/H	T650/H	T770/H	T870/H	S70	S100	S450	S510	S530/H	S550/H	S570/H	S590/H	S630/H	S650/H	S770/H	S850/H	A770/H
Sod Layer, 185 cm	6906783			X	X	X	X	X			X	X	X	X	X	X	X	X	X	X	X